

# Application Note for E909.05 and E909.6 for coordinates 3D 4.0

---

Mechaless Systems GmbH

Names of all products in this publication are used for identification purposes only and are trademarks and/or registered trademarks of their respective owners. Mechaless Systems GmbH makes no claim of ownership or corporate association with the products or companies that own them.

Copyright© 2008 by Mechaless Systems GmbH  
Albert-Nestler-Strasse 10  
D 76131 Karlsruhe  
Germany

## LIMITED WARRANTY

THERE IS NO WARRANTY FOR THE CORRECTNESS OF THIS PUBLICATION OR THE RELATED CODE EXAMPLES OR RELATED PROGRAMS TO THE EXTENT PERMITTED BY APPLICABLE LAW EXCEPT WHEN OTHERWISE STATED IN WRITING. THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PUBLICATION OR THE PUBLISHED CODE EXAMPLES OR RELATED PROGRAMS "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PUBLICATION OR THE PUBLISHED CODE EXAMPLES OR RELATED PROGRAMS IS WITH YOU. SHOULD THE PUBLICATION OR THE PUBLISHED CODE EXAMPLES OR THE RELATED PROGRAMS PROVE TO BE INCORRECT OR DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT, UNLESS REQUIRED BY APPLICABLE LAW, WILL THE COPYRIGHT HOLDER OR ANY OTHER PARTY BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THIS PUBLICATION OR THE PUBLISHED CODE EXAMPLES OR THE RELATED PROGRAMS (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR FAILURE OF THE PROGRAMS/PROGRAM EXAMPLES TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF THE COPYRIGHT HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.



# Chapter 1

## Application Note for E909.05 and E909.6 for coordinates 3D File Index

### 1.1 Application Note for E909.05 and E909.6 for coordinates 3D File List

Here is a list of all documented files with brief descriptions:

<a href="#">main.c</a> (Application Example to demonstrate the usage of the c3d library (lib_c3d) for the HALIOS IC E909.05 and E909.06 ) . . . . .	3
<a href="#">main.h</a> . . . . .	19



# Chapter 2

## Application Note for E909.05 and E909.6 for coordinates 3D File Documentation

### 2.1 main.c File Reference

Application Example to demonstrate the usage of the c3d library (lib\_c3d) for the HALIOS IC E909.05 and E909.06.

```
#include "firmware.h"  
#include "main.h"  
#include "user_space.h"  
#include "haliostools.h"  
#include "c3d.h"  
#include "usb.h"
```

#### Defines

- #define [USB\\_PIN](#) BIT1

#### Functions

- const uint16\_t gui\_applicationVersion [\\_\\_attribute\\_\\_](#) ((section(".application\_version")))
- void [isr\\_gpio\\_falling](#) (void)

- void `isr_wakeup` (void)
- int `main` (int argc, char \*argv[ ])

### Variables

- volatile uint16\_t `gui_doUsb` = 1
- volatile uint16\_t `gui_measurement` = 0
- const char `gArc_project_number` [ ] = "0908503"

### 2.1.1 Detailed Description

Application Example to demonstrate the usage of the c3d library (lib\_c3d) for the HALIOS IC E909.05 and E909.06.

**Author:**

Florian Degler, Mechaless Systems GmbH

**Date:**

Created: 2008-11-18

**Author:**

Roland Muenzer, Media System Consulting

**Date:**

Changed: 2008-12-03 Reworked documentation

**Author:**

Florian Degler, Mechaless Systems GmbH

**Date:**

Changed: 2010-05-28 Reworked for firmware V4.0

**Author:**

Markus Kilian, Mechaless Systems GmbH

**Date:**

Changed: 2010-05-31 Reworked for firmware V4.0

**Id**

[main.c](#),v 1.2 2010/06/18 15:30:23 mki Exp

Definition in file [main.c](#).

## 2.1.2 Define Documentation

### 2.1.2.1 #define USB\_PIN BIT1

Define the hardware input pin which is connected to IC Max3420 for USB-request. For base-board its always GPIO\_1

Definition at line 68 of file main.c.

## 2.1.3 Function Documentation

### 2.1.3.1 `const uint16_t gui_applicationVersion __attribute__((section(".application_version")))`

Set a project application version number. Set to a fix area at FLASH to make possible read out in output file and verify the flashed code.

### 2.1.3.2 `void isr_gpio_falling (void)`

Interrupt function Falling edge at Pin 1 is a USB-request from Master

```
*/  
if (PONEDGE_STAT & USB_PIN)  
{  
    gui_doUsb = 1;  
    g_status0.wakeupEnd = 1;  
}  
  
PONEDGE_CLR = 0x3F;  
/**
```

Definition at line 74 of file main.c.

References gui\_doUsb, and USB\_PIN.

### 2.1.3.3 void isr\_wakeup (void)

Interrupt function Wakeup occurred - Set wuakeupEnd and do a measurement

Definition at line 93 of file main.c.

References gui\_measurement.

### 2.1.3.4 int main (int argc, char \* argv[])

main

#### Parameters:

← *argc* dummy parameter

← *argv* dummy parameter

```

**/
uint16_t ui_cnt;
loopConf_t t_loopConf;

/* variables for filter and calibration functions */
uint16_t ui_filtervalue, ui_quiescent;
uint16_t ui_autocatch = 0;
uint16_t ui_quis_min;
Calib_Result_t t_calib_result = Calib_Nothing_Done;
uint16_t ui_lastCalibTimestamp[LOOPMAXCOUNT];
uint16_t ui_oldCalTime = 0;

/* variables for c3d */
int16_t Ari_c3dPos[3] = { 0, 0, 16 };
uint16_t Arui_loop[4];
uint16_t Arui_quisLoop[4];

/**
 * Initializes the HALIOS SFRs and set up the basic functions of hardware.
 * @n It is recommend to call this function as first call.
 *
 * @post The system is configured:
 * - The trimmvalues are read from InfoBlock and set to
 * mclk and wkclk (only at (E909.05)
 * - Following interrupts are enabled:
 * - HALIOS measurement ready
 * - wakeup timer
 * - Following GPIO settings are used:

```

```
*      - The RDY_PIN will set as output,  
*          if no readypin is needed set RDY_PIN as 0  
* - Wakup timer enabled and set to 10 ms, used for sample time  
* - One HALIOS loop enabled and set up (one LED against compensator).  
*  
* @param [in] BIT0 Set a GPIO as trigger pin for measurement, use only one bit.  
*          If not needed set to 0.  
*/  
haliosInitialize(BIT0);  
  
/**  
* Set the projectnumber (eight characters) to g_sfr.project_number to make  
* readable about the constant reading mechanism @ref paramCheckSfr.  
*  
* @param[in]   gArc_project_number Pointer to a string. The maximum numbers of eight ch  
*/  
paramSetProjectNr((uint8_t*)(gArc_project_number));  
  
/** Setup the register of the watchdog timer0.  
*  
* Configure the watchdog in milliseconds (ms).  
*  
* @param[in] 500 Watchdogtime in ms.  
* @n Must be smaller than 500 seconds (s)!  
* @n Higher Values will ignore and set to 500 s  
*/  
deviceSetWatchdogTime (500UL);  
  
/** set IO port function to GPIO for all pins */  
POCFG = 0;  
  
/**  
* Define which communication device will be used and enable or disable the  
* related interrupts.  
* @n This function is optional. If this function is not called, communication  
* devices set all to off.  
*  
* @param[in] DEVCOM_I2C set communication to I2C  
* - For no communication device use (@ref DEVCOM_NO_COMM)  
* - For I2C (@ref DEVCOM_I2C)  
* - For SPI (@ref DEVCOM_SPI).  
* - For SPI and I2C (@ref DEVCOM_I2C | @ref DEVCOM_SPI)  
*/  
deviceSetCommDevice(DEVCOM_I2C);  
  
/**  
* Call this function to show the last reset reason at a pin  
* by a significant bit pattern.  
* @n This function is optional. Use only if you don't want to  
* do your own fail state.  
* @n
```

```

* @n Count the blink sequence of the output pin:
* - 4 times blinking: watchdog reset
* - 5 times blinking: CPU register parity error
* - 6 times blinking: FLASH uncorrectable bit error
* - 7 times blinking: RAM perity error
* - 8 times blinking: Trap
* @n @n
* @param[in] outputPin Define the pin which should do the failState show
* @param[in] inputPin Define the pin which break the failState show.
*                               Set to 0 if now break is required
*/
failState(BIT2, BIT3);

/**
* Compute the checksum over all words in "Parameter FLASH Area".
* If the Checksum proofs "Valid Data", data is copied from the
* "Parameter FLASH Area" into RAM.
*
* @return
*   - -1: No valid data found.
*   - else: Number of copied words.
*/
if (deviceRestore() == -1)
{
    /**
    * Set the sample time in milli seconds. The wakeup timer
    * of the Analog Control Module is used for the timing.
    * Depending on the communication device the micro-controller
    * switches to STANDBY or STOP mode.
    *
    * @note time in milli seconds, must be between 2 and 32, only even
    * values are accepted. (See also description of the Analog Control Module).
    */
    paramSetSampleTime(8);

    /**
    * Set the amount of active loops.
    *
    * @param[in] count Amount of active loops. @a count must be less or equal to
    * @ref LOOPMAXCOUNT.
    * @return An element of the @a HaliosCode enumeration:
    *   - HALIOS_OK: No error occurred
    *   - HALIOS_PARAM: Wrong parameter for count passed.
    */
    haliosSetLoopCount(4);

    /**
    * Configuration of the 1st loop.
    * This is an example how to use type loopConf_t for loop configuration.
    * The values are indices for the LED current of the ASIC.
    */

```

```
t_loopConf.loopNr = 0;
t_loopConf.ledConf = H_LED3B | H_LED5A | H_AON | H_ACCON;
t_loopConf.phaseA.range = 10;
t_loopConf.phaseA.offset = 22;
t_loopConf.phaseB.range = 15;
t_loopConf.phaseB.offset = 15;
t_loopConf.iConfC = 0;
t_loopConf.DC_offset = 0;
t_loopConf.PreAmp = 0;
t_loopConf.ClockConf = 0;

/**
 * Store the configuration data into the virtuel loops at SFR by using
 * a struct @ref LoopConf.
 *
 * @param[in] t_LoopConfig The LED and current configuration.
 *
 * @return An element of the @ref HaliosCode enumeration:
 * - HALIOS_OK: No error occurred
 * - HALIOS_PARAM: Wrong parameter in @a t_LoopConfig passed.
 */
haliosLoopInit(t_loopConf);

/**
 * Store the configuration data into the virtuel loops at SFR by direct access.
 *
 * @note No validation check will done. It is recomand to use
 * the function @ref haliosLoopInit.
 *
 * @param[in] loopNr 0 .. @ref LOOPMAXCOUNT
 * @param[in] ledConf LED and measurement configuration.
 * @param[in] iClockConf Measurement Configuration HALIOS Clock
 * @param[in] iConfA Current configuration for phase A.
 * @param[in] iConfB Current configuration for phase B.
 * @param[in] iConfC Current configuration for the compensator offset.
 * @param[in] iPreAmp Preamplifier Configuration
 */
haliosLoopInitialize(1, 20993, 0, 875, 495, 27, 0);
haliosLoopInitialize(2, 20996, 0, 810, 495, 25, 0);
haliosLoopInitialize(3, 21056, 0, 908, 495, 29, 0);
haliosLoopInitialize(4, 21077, 0, 3, 1023, 127, 0);

/**
 * Set System Status to be used for @ref deviceWaitForTimer during wait
 * until timer has elapsed or a interrupt wakes up the system.
 * @n This function is optional. If not called system status is STANDBY.
 * @n
 * @param[in] SystemStatus Selects system mode for deviceWaitForTimer
 * - DEVSET_RUN: Keep System in RUN Mode in deviceWaitForTimer
 * - DEVSET_STANDBY: Switch to STANDBY Mode in deviceWaitForTimer
 * - DEVSET_STOP: Switch to STOP Mode in deviceWaitForTimer
```

```

* - DEVSET_OFF:          Switch to OFF Mode in deviceWaitForTimer
*
* Keep in mind that spi-usb communication only works in RUN and in STANDBY mode.
*/
deviceSetSystemStatus(DEVSET_STANDBY);

/** Settings for filter and calibration in the user space */
paramSetValue(RAM_FILT_BORDER, HALIOS_FILT_8); /* filter depth */
paramSetValue(RAM_FILT_BREAK, 10);           /* filter break */
paramSetValue(RAM_CAL_TUBE, 32);             /* tube around target value */
paramSetValue(RAM_CAL_TIME, 300);           /* time for calibration */
paramSetValue(RAM_CAL_DCNT, 8);             /* value for movement detection with L
paramSetValue(RAM_CAL_TARGET_VALUE, 100);    /* target value for calibration */

/** Set quiescent-value for the loops */
for (ui_cnt = 0; ui_cnt < haliosGetLoopCount(); ui_cnt++)
    paramSetValue(RAM_QUIESCENT_LOOP0 + (ui_cnt * BLOCK_SIZE), paramGetValue(RAM_C

/** Switch Calibration
* Application options are:
* CAL_START - calibration on start up
* CAL_TIME - calibration for time
* CAL_AUTO_CATCH - enable autocatch function
*/
paramSetValue(RAM_CAL_SETUP, ( CAL_START | CAL_TIME ));

/** Settings for c3d, constants are defined in c3d.h */
paramSetValue(RAM_C3D_X_SCALE, XSCALE);
paramSetValue(RAM_C3D_Y_SCALE, YSCALE);
paramSetValue(RAM_C3D_Z_SCALE, ZSCALE);
paramSetValue(RAM_C3D_X_OFFSET, XOFFS);
paramSetValue(RAM_C3D_Y_OFFSET, YOFFS);
paramSetValue(RAM_C3D_X_FACT, XFACT);
paramSetValue(RAM_C3D_Y_FACT, YFACT);
paramSetValue(RAM_C3D_Z_FACT, ZFACT);
paramSetValue(RAM_C3D_ROT, 0);
paramSetValue(RAM_C3D_FLIP, 0);

/** Set the time (maximum time, some USB controller call more
than this value!) the PC requests for new values. */
paramSetValue(RAM_USB_CALL_TIME, 8);
}

/**
* Check the contents of SFR and does any special functions.
* If the content of a SFR register has changed the new values will be copied
* into the corresponding firmware functions or corresponding hardware registers.
* - Set size of SFR and user space to address @ref BUFFSIZE at SFR
* - Set constant reading values to SFR controled by @ref READ_CONST_CMD
* - Set systemStatus

```

```

*   - Set Communication device
*   - Set samplettime
*   - Use spezial functions (use careful)
*   - Set main clock (ANALOG_MCLK) (Only E909.05)
*   - Set wakeup clock (ANALOG_WKCLK) (Only E909.05)
*   - Set HALIOS frequency (Only E909.06)
*   - Set number of Loops to g_sfr.loopCount
*/
paramCheckSfr();

/** Set GPIO 2..5 as output pins */
PDIR &= ~(BIT2 | BIT3 | BIT4 | BIT5);

/**
 * @brief Function o init the HALIOS tools
 *
 * Initialize the structures for filtering and calibration.
 */
init_haliostools();

/** Initialize module coordinates 3D */
c3dInitialize( paramGetValue(RAM_C3D_X_SCALE)
, paramGetValue(RAM_C3D_Y_SCALE)
, paramGetValue(RAM_C3D_Z_SCALE) );

/**
 * @brief Warmup the HALIOS loops.
 *
 * Function from HALIOS Tools. Do some measurements for each loop to ensure
 * that the measuerment counter has reached its actual value.
 *
 * @param[in] times How many times to start an empty measurement to warm up the
 * loops:
 * - HALIOS_WARMUP_FULL: 6 times for a full range of 1024 steps
 * - HALIOS_WARMUP_HALF: 3 times for a half range of 512 steps
 */
haliosWarmup(HALIOS_WARMUP_FULL);

/**
 * Force a calibration for each active loop.
 */
if (paramGetValue(RAM_CAL_SETUP) & CAL_START)
{
    for (ui_cnt = 0; ui_cnt < paramGetSFR(LOOPCOUNT); ++ui_cnt)
    {
        t_calib_result = haliosCompCalib(ui_cnt, haliosGetResult(ui_cnt), \
            paramGetValue(RAM_CAL_TARGET_VALUE),
            paramGetValue(RAM_CAL_TUBE), 0, 1023);
        paramSetValue( ((ui_cnt * BLOCK_SIZE) + RAM QUIESCENT_LOOP0), g_calib[ui_cnt].
    }
}

```

```

for(ui_cnt = 0; ui_cnt < LOOPMAXCOUNT; ui_cnt++)
{
    /* Initialize the last calibration-time-stamp variable for calibration */
    ui_lastCalibTimestamp[ui_cnt] = 0;
}

#if (USB != USB_OFF)
/**
 * Initialize the SPI module and the MAX3420E SPI-USB bridge.
 *
 * @post GPIO 2..5 configured for SPI
 */
usbInitialize(USB_PART_ON, USB_PIN, paramGetValue(RAM_USB_CALL_TIME));

/* set interrupt for falling signal on the interrupt request pin */
PONEDGE_EN |= USB_PIN;
/* set interrupt mask for falling signal on a GPIO */
IRQ_MASK_H |= VBH_GPIO_FALLING;
#endif

/** Set application bit and Version */
g_sfr.inst_libs |= BIT15;
deviceCheckVersion(BIT15, gui_applicationVersion);

/**
 *
 * Do the measurement in an endless loop
 *
 */
while (1)
{
    /**
     * Start and retrigger the watchdog timer. This is an inline function.
     *
     * @note At E909.06: After first call of watchdog it is not possible
     * to disable the watchdog or change the watchdog time.
     *
     */
    KICKDOG();

    /**
     * Check the contents of SFR and does any special functions.
     * If the content of a SFR register has changed the new values will be copied
     * into the corresponding firmware functions or corresponding hardware registers.
     * - Set size of SFR and user space to address @ref BUFFSIZE at SFR
     * - Set constant reading values to SFR controled by @ref READ_CONST_CMD
     * - Set systemStatus
     * - Set Communication device
     * - Set sampletime
     * - Use spezial functions (use careful)
     */
}

```

```

* - Set main clock (ANALOG_MCLK) (Only E909.05)
* - Set wakeup clock (ANALOG_WKCLK) (Only E909.05)
* - Set HALIOS frequency (Only E909.06)
* - Set number of Loops to g_sfr.loopCount
*/
paramCheckSfr();

if (gui_measurment == 1)
{
    gui_measurment = 0;

    /**
    * Do the HALIOS measurement of all configurated loops.
    * - Enable the analog part
    * - Start one Warmup to engage the analog part
    * - Start the configured measurements
    * - disable the analog part
    * - count up the @ref TIME_STAMP
    *
    * When haliosMeasure() is called with parameter HALIOS_RDYON,
    * the configured PIN in haliosInitialize() will be switched on
    * when entering the haliosMeasure() function,
    * and will be switched off when haliosMeasure() is left.
    *
    * @param[in] readyPin @ref HaliosCode
    *             - @ref HALIOS_RDYON GPIO is used as ready pin.
    *             - @ref HALIOS_RDYOFF GPIO is not used as ready pin.
    */
    haliosMeasure(HALIOS_RDYON);

    /**
    * Filter the loops and check the calibration.
    */
    ui_autocatch = 0;
    for (ui_cnt = 0; ui_cnt < paramGetSFR(LOOPCOUNT); ++ui_cnt)
    {
        /**
        * @brief Filter the loop with a low pass filter.
        *
        * @param[in] loopNr      Number of the loop (0 .. LOOPCOUNT).
        * @param[in] border3db  The 3dB border of the low pass filter.
        * @param[in] filterBreak If the derivation of the raw loop value is high
        *                        than filterBreak the filtered value is omitted
        *                        the raw loop value will be written to loopFilter
        *                        negative value for filterBreak disables the filter
        *                        break mechanism.
        *
        * @return      filter_value the software filtered value
        */
        ui_filtvalue = haliosFilterLoop(ui_cnt, \

```

```

        (HALIOS_FILT)paramGetValue(RAM_FILT_BORDER), \
        paramGetValue(RAM_FILT_BREAK));

/** Set filtervalue to user space */
paramSetValue( (RAM_FILT_LOOP0 + (ui_cnt * BLOCK_SIZE)) , ui_filtervalue);

if (paramGetValue(RAM_CAL_SETUP) & CAL_TIME)
{
    /**
     * When the autocatch function cause a calibration it sets the time for
     * So this forces a calibration immediately.
     * The variable ui_lastCalibTimestamp prevents that autocatch enforces
     * That's necessary because if no sensor is connected or the optical c
     * value is below quiescent value and probably around zero.
     */
    if (paramGetValue(RAM_CAL_SETUP) & CAL_AUTO_CATCH)
    {
        if ( paramGetValue(RAM_QUIESCENT_LOOP0 + (ui_cnt * BLOCK_SIZE)) <=
        {
            ui_quis_min = paramGetValue(RAM_QUIESCENT_LOOP0 + (ui_cnt * BL
        }
        else
        {
            ui_quis_min = paramGetValue(RAM_QUIESCENT_LOOP0 + (ui_cnt * BL
        }

        /**
         * Force calibration when current value
         * is below saved quiescent value
         */
        if ((ui_autocatch == 0) && ((ui_filtervalue < ui_quis_min) || (ui_c
            && (ui_lastCalibTimestamp[ui_cnt] > 50))
        {
            ui_autocatch = 1;
            ui_oldCalTime = paramGetValue(RAM_CAL_TIME);
            paramSetValue(RAM_CAL_TIME, 0);
            ui_lastCalibTimestamp[ui_cnt] = 0;
        }
        else if ((ui_lastCalibTimestamp[ui_cnt] <= 50) \
            && ((ui_filtervalue < ui_quis_min) || (ui_quis_min == 0)))
        {
            ui_lastCalibTimestamp[ui_cnt]++;
        }
        else if ((ui_lastCalibTimestamp[ui_cnt] != 0) && (ui_filtervalue >
        {
            ui_lastCalibTimestamp[ui_cnt] = 0;
        }
    }

    /**
     * @brief

```

```

* Calibrate the passed loop. This function counts the calls for each loop.
* The function checks if a movement can be detected. In case of a movement the
* counter will reset. If no movement for countEnd has been detected the function
* checks if the loop is in the tube around the target value (target value + tube).
* If the loop is outside the tube the compensator offset will be changed to
* to reach the target value again. In case of a balanced loop the compensator
* offset from both sender and receiver will be influenced.
* This is important when a static object has been detected or the optical axis
* of the sensor has changed.
*
* @param[in] nr          number of the loop (0 .. LOOPCOUNT)
* @param[in] loopValue  actual value of the signal
* @param[in] target     target value for the idle loop
* @param[in] tube       If the loop is within the tube borders (targetValue - tube <
*                       loopValue < targetValue + tube) then the actual value
*                       is fetched as the new reference value. If the derivation
*                       is smaller than maxDCnt. If the value is outside the calibration
*                       tube the compensator offset current is calibrated.
* @param[in] countEnd  If the loop value is count times between targetValue and
*                       targetValue + tube then a new reference value is detected.
*                       If count is zero the function immediately starts a new
*                       calibration.
* @param[in] maxDCnt   If the derivation is greater than maxDCnt then the
*                       calibration is aborted and counter gets a new value.
*/
t_calib_result = haliosCompCalib(ui_cnt, ui_filtervalue, \
    paramGetValue(RAM_CAL_TARGET_VALUE), \
    paramGetValue(RAM_CAL_TUBE), \
    ((uint32_t)(paramGetValue(RAM_CAL_TIME)) * 100), \
    paramGetValue(RAM_CAL_DCNT));

/** Save the new quiescent value to user space */
if (t_calib_result != Calib_Nothing_Done)
{
    paramSetValue(RAM QUIESCENT_LOOP0 + (ui_cnt * BLOCK_SIZE), g_calib_result);
}

/** Set calibTime to old value */
if (ui_oldCalTime != 0)
{
    paramSetValue(RAM_CAL_TIME, ui_oldCalTime);
    ui_oldCalTime = 0;
}
} /* calibration time */

/** Compute amplitude for the loop */
ui_quiescent = paramGetValue(RAM QUIESCENT_LOOP0 + (ui_cnt * BLOCK_SIZE));
if (ui_filtervalue > ui_quiescent)
{
    paramSetValue(RAM_AMPLITUDE_LOOP0 + (ui_cnt * BLOCK_SIZE), ui_filtervalue);
}

```

```

    , (ui_filtvalue - ui_quiescent) );
}
else
{
    paramSetValue( RAM_AMPLITUDE_LOOP0 + (ui_cnt * BLOCK_SIZE) , 0);
}

    /* filter loops and check calibration */

    /** Set loop- and quiescent-array for C3D */
    for (ui_cnt = 0; ui_cnt < 4; ui_cnt++)
    {
        /** Set filtered values to an array of for loops */
        Arui_loop[ui_cnt] = paramGetValue(RAM_FILT_LOOP0 + (ui_cnt * BLOCK_SIZE));

        /** Set the quiescent values to an array */
        Arui_quisLoop[ui_cnt] = paramGetValue(RAM_QUIESCENT_LOOP0 + (ui_cnt * BLOCK_SIZE));
    }

    /*
    * This function calculates three dimensional
    * coordinates { x, y, z }.
    *
    * @pre - loop 0 and loop 1 are used to calculate the x coordinate.
    *       - loop 2 and loop 3 are used to calculate the y coordinate.
    *       - loop 0 .. loop3 are used to calculate the z coordinate.
    *       - Loop 0 .. loop 3 should be configured in a way, that
    *         one LED in phase B adjusts against the compensator in
    *         phase A.
    *
    * @param[in]  loop      pointer to an array of loop values
    *
    * @param[in]  quis_loop pointer to an array of quiescent values
    *              for the corresponding loop values
    *
    * @param[in]  xFact     multiply the found x position (-1 .. 1)
    *                      with xFact.
    * @param[in]  yFact     multiply the found y position (-1 .. 1)
    *                      with yFact.
    * @param[in]  zFact     multiply the found z position (0 .. 1)
    *                      with zFact.
    *
    * @param[in]  xOffs     add xOffs to the computed
    *                      x position value.
    * @param[in]  yOffs     add yOffs to the computed
    *                      y position value.
    *
    * @param[out] *pos      pointer to an array where the three
    *                      computed coordinates { x, y, z } are
    *                      saved.
    *
    */

```

```

    */
    c3d(Arui_loop, Arui_quisLoop, Ari_c3dPos, paramGetValue(RAM_C3D_X_OFFSET), \
paramGetValue(RAM_C3D_Y_OFFSET), paramGetValue(RAM_C3D_X_FACT), \
    paramGetValue(RAM_C3D_Y_FACT), paramGetValue(RAM_C3D_Z_FACT));

    /*
    * Rotate the position and mirror it on the determined axis.
    *
    * @note    *pos    The position to rotate, the rotated value is also
    *            stored there.
    * @note    rot     The angle to rotate the position counter clock
    *            wise. Only the following angle values are
    *            supported:
    *            0, 45, 90, 135, 180, 225, 270, 315.
    * @note    flip    Determine how to mirror the position on the axis.
    *            Only the following values are supported:
    *            M3D_FLIP_OFF, M3D_FLIP_X, M3D_FLIP_Y
    */
    c3dRotFlip(Ari_c3dPos, paramGetValue(RAM_C3D_ROT), paramGetValue(RAM_C3D_FLIP))

    /** Store the data in the user space */
    paramSetValue(RAM_C3D_X, Ari_c3dPos[0]);
    paramSetValue(RAM_C3D_Y, Ari_c3dPos[1]);
    paramSetValue(RAM_C3D_Z, Ari_c3dPos[2]);

} /* if measuerment */

#if (USB != USB_OFF)

/**
 * If Interrupt falling edge was caused by Pin 1 do a USB transfer
 */
if (gui_doUsb == 1)
{
    /**
    * If USB-request occurred during a measurement
    * clear the wakeupEnd flag
    */
    g_status0.wakeupEnd = 0;

    gui_doUsb = 0;

    /** Do transmission */
    usbHacoHandleIrqs();
}
#endif

/**
 * Wait until the timer has elapsed.
 */
deviceWaitForTimer();

```

/\*\*

Definition at line 106 of file main.c.

References CAL\_AUTO\_CATCH, CAL\_START, CAL\_TIME, gArc\_project\_number, gui\_do-  
Usb, gui\_measurment, and USB\_PIN.

## **2.1.4 Variable Documentation**

### **2.1.4.1 volatile uint16\_t [gui\\_doUsb](#) = 1**

Global variable for communication between Interrupt and USB-Part in main

Definition at line 40 of file main.c.

### **2.1.4.2 volatile uint16\_t [gui\\_measurment](#) = 0**

Global variable for synchronize the measueremt with configured sample time

Definition at line 46 of file main.c.

## 2.2 main.h File Reference

### Defines

- #define [APPLICATION\\_VERSION](#) 101UL
- #define [USB\\_OFF](#) 1
- #define [USB\\_HACO](#) 2
- #define [USB\\_MOUSE](#) 3
- #define [USB\\_KEYB](#) 4
- #define [USB](#) USB\_HACO
- #define [LIN\\_OFF](#) 0
- #define [LIN\\_ON](#) 1
- #define [LIN](#) LIN\_OFF
- #define [CAL\\_OFF](#) 0
- #define [CAL\\_START](#) BIT0
- #define [CAL\\_TIME](#) BIT1
- #define [CAL\\_AUTO\\_CATCH](#) BIT2

### 2.2.1 Detailed Description

Header file for the example application.

**Author:**

Miroslav Ostric, Mechaless Systems GmbH

**Date:**

Created: 2007-03-13

**Author:**

Roland Muenzer, Media System Consulting

**Date:**

Changed: 2008-11-26 added comments, added missing include "firmware.h"

**Author:**

Florian Degler, Mechaless Systems GmbH

**Date:**

Changed: 2010-05-28 Reworked for firmware V4.0

**Author:**

Markus Kilian, Mechaless Systems GmbH

**Date:**

Changed: 2010-05-31 Reworked for firmware V4.0 added comments, removed obsolete include "firmware.h"

**Author:**

Markus Kilian, Mechaless Systems GmbH

**Date:**

Changed: 2010-07-13 Due to compatibility for GCC firmware library 4.01 available. Application version set to 1.01.

Definition in file [main.h](#).

## **2.2.2 Define Documentation**

### **2.2.2.1 #define APPLICATION\_VERSION 101UL**

Version number for the application.

Definition at line 27 of file main.h.

### **2.2.2.2 #define USB\_OFF 1**

Standalone application, no USB support.

Definition at line 30 of file main.h.

**2.2.2.3 #define USB\_HACO 2**

USB support for the MAX3420E USB-SPI bridge, e.g. like on the E909.05A baseboard.

Definition at line 36 of file main.h.

**2.2.2.4 #define USB USB\_HACO**

Software switch to choose between standalone mode and USB support.

Definition at line 41 of file main.h.

**2.2.2.5 #define LIN\_OFF 0**

Definitions for LIN module

Keep in mind: LIN can only be used with E909.06

Definition at line 49 of file main.h.

**2.2.2.6 #define CAL\_OFF 0**

Bit definitions for calibration

Definition at line 57 of file main.h.

# Index

`__attribute__`  
main.c, 5

APPLICATION\_VERSION  
main.h, 20

CAL\_OFF  
main.h, 21

gui\_doUsb  
main.c, 18

gui\_measurment  
main.c, 18

isr\_gpio\_falling  
main.c, 5

isr\_wakeup  
main.c, 6

LIN\_OFF  
main.h, 21

main  
main.c, 6

main.c, 3  
\_\_attribute\_\_, 5  
gui\_doUsb, 18  
gui\_measurment, 18  
isr\_gpio\_falling, 5  
isr\_wakeup, 6  
main, 6  
USB\_PIN, 5

main.h, 19  
APPLICATION\_VERSION, 20  
CAL\_OFF, 21  
LIN\_OFF, 21  
USB, 21

USB\_HACO, 20

USB\_OFF, 20

USB  
main.h, 21

USB\_HACO  
main.h, 20

USB\_OFF  
main.h, 20

USB\_PIN  
main.c, 5